

Directions For Use

6% Hydrogen Peroxide Go-No-Go

- 1 Uncap a vial and add **1 drop** of Indicator Solution.
- 2 Place a pipette tip firmly onto the end of the pipettor.
- 3 Depress the pipette plunger, then immerse the tip in the solution to be tested. Release the pipette plunger. Sample will be drawn into the pipette tip.
Caution: Use of good pipetting technique is critical to obtaining accurate test results. Make sure that the pipette tip is not in contact with the bottom of the sample container when the plunger is released. The tip must be unobstructed.
- 4 Holding the pipettor over the test vial, depress the pipette plunger to dispense the sample. Foaming will likely occur when the sample mixes with the reagent.
- 5 Re-cap the vial and shake it briefly to mix the contents. Wait **2 minutes** for reagent color to stabilize.



FAIL FAIL PASS PASS
BELOW 6.0% ABOVE 6.0%